

ROMTER IIIA Installation

1. Unzip the WRT3.ZIP into a directory you like, such as \WRT3

```
C:\WRT3\  ├── USB_Driver\  ├── Siexpusb.cat
           ├── .        ├── SiF32x_USB.inf
           ├── .        ├── SiF32x.sys
           ├── .        ├── SiLib.sys
           ├── .        └── Wdmstub.sys
           ├── Wrt3.exe
           ├── Hellort3.dll
           └── SiF32xUSB.dll
```

2. If you like to install the LPT driver, right click the file "Setup_9x.inf" (for Win98) or "setup_nt.inf" (for Win2000/xp) and click "install".
3. If you like to install the USB driver(Win2000/XP only), plug the USB-LPT adapter into the PC. When the PC ask for the driver's location for this new hardware, point to C:\WRT3\USB_Driver
4. After the installation completed, run "Wrt3.exe" to start the emulation.